



The Newest 180 Degree Convex Rear View Mirror Installation Instruction

We are striving to build an reliable brand of golf carts parts and accessories.

Hope this manual can assist you to easier install.

For more technical support, please reach us via

Website : www.10LOL.com

Email : sale_service@10LOL.com

Facebook : zhong zaiyang

Youtube : 10LOL

Contents	Qty	Installation Tools	Qty
Small Washer.....	1	Phillips Head Screwdriver.....	1
Large Washer.....	1	12mm Wrench.....	1
Iron Sheet.....	1	10mm Wrench.....	1
Shell Combination.....	2		
Small Screw.....	2		
Bolt.....	2		
Nuts.....	2		
Large Screw.....	4		

(See figure 1)



Installation Tools



Phillips head screwdriver



12mm Wrench



10mm Wrench

Installation Steps



1. Combine the two modules



2. Screw on the black screw.



3. Place the iron piece



4. Tighten with a Phillips head screwdriver