



1-Anti dust ring  
2-Bearing  
3-Front Cover  
4-O-rings  
5-Drive Shaft  
6-Oil Seal  
7-Bearing  
8-Washer  
9-Snap ring  
10-Stator

11-Rotor  
12-Roller  
13-Oilless bearing (bushings)  
14-Plastic Block  
15-Spring Pin  
16-Plunger Piston  
17-Piston ring  
18-Distributor  
19-Spring  
20-Distributor seal ring

21-Distributor seal ring  
22-Distributor seal ring  
23-O-rings  
24-Rear Cover  
25-Screw  
26-O-rings  
27-Rotary oil seal  
28-Bushing  
29-Brake Cylinder  
30-Screw

31-Brake Shaft  
32-Dynamic Friction Disc  
33-Static Friction Disc  
34-Brake Plunger sealaring  
35-Brake Plunger  
36-Disc Spring  
37-Clip Ring  
38-Cover Plate