



How to installation magnetic track rail


- Material Need :
- A. Magnetic rack rail without power supplier & end cup
 - B. In corner module
 - C. Pass-through module (I shape)
 - D. Corner module (L shape)
 - E. Three direction module (T shape)
 - F. Four direction module (X shape)
 - G. Pail plug fixing parts (end cup)
 - H. External connection module
 - I . Decorative cover

Track rail :




SURFACE MOUNTED TRACK 2
OLEO3-02M


Spare parts :




IN corner module




Pass-through module




Corner module




Three direction module



Four direction module



Rail plug fixing parts




External connection module




Decorative cover

Track installation display

Surface Mounted Track installation



Assembly the shpe you want like below




How to installation magnetic track rail

Material Need :


- A. Magnetic rack rail without power supplier & end cup
- B. L shape connector
- D. X shape connector
- F. Output module
- H. Corner output module
- C. T shape connector
- E. Pail plug fixing parts (end cup)
- G. Straight output module

Track rail :




RECESSED TRACK
OLEO3-03M


Spare parts :




L shape connector



T shape connector




X shape connector




Internal Angle




External Angle



Output module




Straight output module



Corner output module

Track installation display

Recessed Track installation



Assembly the shpe you want like below

