



Ray

WIRELESS EARPHONES

DYNAMIC MODEL Φ9mm DRIVER UNIT

- Bluetooth ver.5.0
- AAC apt-X
- Play time 5 hours
- Call time 5 hours
- IPX 4

Part Name



※ KX-200BT is compatible with most of Bluetooth device. But it still have some device cannot pair with.

Bluetooth Spec.	
Communication System	: Bluetooth 5.0
RF Power Output	: Bluetooth Class 2
Max Connection Distance	: Approx. 10 m
Frequency Band	: 2.4G Hz Band
Support Profile	: A2DP,AVRCP,HFP,HSP
Support Codec	: SBC, AAC, apt-X
Max Play Time	: Approx. 5 Hours
Max Talk Time	: Approx. 5 Hours
Max Standby Time	: Approx. 30 Days
If Charge Time	: Approx. 2 Hours

※ Earphones play times will be influenced by actual operation.

Earphone Spec.	
Type	: Dynamic
Magnet	: High Force Magnet
Drivers Unit	: Φ 9mm Titanium Film
Frequency Response	: 20~20 000Hz
Impedance	: 16Ω * 2
Max Input Power	: 10mW
Sensitivity	: 106dB / 1KHz
Battery	: 40mAh*2 Coin Battery
Cable Length	: 60cm
Charge Port	: MicroUSB Terminal
Charging Cable	: MicroUSB - USB A
Eartips	: Silicone Eartips L · M · S

Sincerely thank you for purchasing this products. Before using, please read through the manual, to ensure that you use the product correctly.

Accessories

Earphones	× 1 Pair
Alternative Ear Tips(L, S, M)	× 3 Pair (M size one are in Earphones)
Charging Box	× 1 Set
Charing Cable (Micro USB-USB2.0/30cm)	× 1 Set
User Manual and Guarantee	× 1 Set

Connect and Pair via Bluetooth

Earphones Adopt

- Before adopting ear hook, Please identify the Left and Right Earphone first. There are difference between L and R earhook.




The First Time Pair with Bluetooth Device

- Press and hold the control function button to power on the product. The product plays a confirmation tone "Power on. Pairing" and the indicator lamp flash in blue and red.

Power Off: Press and hold for a few second. The product will power off after it plays confirmation tone "Power Off" Meanwhile, the indicator lamp in red.

- ※ The product will power off automatically after 5 mins without connecting the device.
- ※ To save the power, Please power off the product if you do not use.



- Use your Bluetooth device to begin the connecting process and search for the product. When your Bluetooth device finds the product, "KX-200BT" will be display on the device. Select "KX-200BT" to connect the product to your Bluetooth device. The product plays a confirmation tone "Connected" after finished.

- ※ Indicator flashes in Blue in this state.

The Second Time Pair with Bluetooth Device


Press and hold the control function button. The product plays confirmation tone " Power on" and standy.

Use your Bluetooth device and the product will connect with the device automatically. The product plays confirmation tone "Connect"

- ※ KX-200BT will connect with device automatically if paired before. In this case, you donot need to pair again.
- ※ When it release the connection with the device, headphones will play confirmation tone "Disconnected" and switch into standy state.



If you fail to pair and connect to the device or a new device, Please turn off and on the the headphone power again, and turn off and on device Bluetooth function again. Then search. The first time pairing and connection need a few seconds to search, After "KX-200BT" showing on the Bluetooth list, then select it.



Please connect and pair with your Bluetooth device first. Use your Bluetooth device to start playback, referring to the device manual as necessary.

Listening to Music

- ※ Please connect and pair with your Bluetooth device first. Use your Bluetooth device to start playback, referring to the device manual as necessary.

Next Song / Volume Up

- Next Song Press and hold when music playing
- Volume Up Press once when music playing

- ※ Continuous press the button volume up more. When it is in the max volume, the product play notice tone.

Play / Pause

- ※ Please play music on your device first.
- Play Music Press
- Pause Music Press

Replay / Pervious Songs / Volume Down

- Previous Song Press and hold 1 second
- ※ If the headphones replay current song after pressing and hold 1 second, please press and hold for 1 second again to play pervious song again.

- Volume Down Press once when music playing
- ※ Continuous press the button volume down more. When it is in the min volume, the product play notice tone.

- △ Selecting music, artist with the products are not available. Please select on your device.
- ※ Some control of devices may not available for music, video playback on some devices. In this case, please control on your devices.

Talking to the Phone

- ※ If your Bluetooth devices supports telephone features, you can use the microphone built into the product to talk on the phones.

Volume Up

- Volume Up Press once when talking.

- ※ Continuous press the button volume up more. When it is in the max volume, the product play notice tone.

Answer / End / Rejection

- Answer Press once when calling income.
- End Press once when talking.
- Rejection Press twice when talking.

- ※ If you need to redial call , press twice. The product will play confirmation tone " Redialing" .

Volume Down

- Volume Up Press once when talking.

- ※ Continuous press the button volume down more. When it is in the min volume, the product play notice tone.

- △ Some controls may not available for talking on some devices or APPs.
- ※ Signal transmit will affected by your circumstance, If you hear the noise or unstable sound when talking, please change a place.

Multi-Pairing Function

The product has a multi-pairing function that can record 8 devices which pair before.

Please follow "Connect and Pair via Bluetooth" to pair with a new device. When switching to a new Bluetooth device, you may not be able to pair because the previously connected Bluetooth device cannot be disconnected. Please ensure disconnection status before pairing.


- ※ The product can record 8 devices. When the product needs to record the ninth device, it will forget the first record automatically.
- ※ If you pair with a second device, please ensure the product has disconnected with the first device.



Replacing the Eartips

The product includes silicone eartips in 3 sizes (XS, S, M). At the time of purchase, the M-size silicone eartips are attached.

- ※ To ensure the best sound quality, select the eartips that is best for you, and adjust the eartips inside your ears for a snug fit. Inappropriate eartips will lead you to be difficult to hear bass sounds.



Bluetooth Troubleshooting

Problems about Pairing, no sound and the solution.

- Obstacles between product and the Bluetooth device, such as people, metal, walls and place the product and device closer together.
- Place the product and the Bluetooth device within 10m of each other.
- The product may be unable to pair if Bluetooth device connects to the product and Wi-Fi in the same time.
- Turn off Wi-Fi and pair the product with the Bluetooth device again.
- The product is unable to connect or control due to APPs and other products has connected your Bluetooth devices.
- Turn off the APPs and make sure your Bluetooth device has not connected with other product.

Please follow these solutions as follow

- Delete the record on your Bluetooth devices, and follow step "Connect and Pair via Bluetooth" to pair again
- Turn off the product and Bluetooth device power and pair again.
- Recharge the product with charging case.

Notice of Bluetooth / Others

- Do not use the product near the medical equipment. Radio waves may affect cardiac pacemakers and medical electronic equipment. Do not use the product in medical facilities and keep 3m distance at least from them..
 - Do not subject the product to strong impact to avoid electric shock, malfunction or fire.
 - Do not lead the distance between Bluetooth device and the product out of 10m. It will lead unstable connection.
 - Sound transmission may be affected if you put the Bluetooth device into the handbag while working.
 - Do not disassemble, modify or attempt to repair the product to avoid electric shock, fire and malfunction.
 - Do not put foreign matter such as combustible materials, metal or liquid in the product.
- ※ Damage caused by the use of this product, our company shall not bear any liability except for legally recognized liability for compensation.
 - ※ We can not assure the product connects all Bluetooth devices will be successful, our company shall not be liable for any communication error or abnormality of the customer's connection equipment.
 - In order to improve the product, the specifications and appearance will also be changed without notice, please understand
 - We will replace the defective products with new ones for manufacturing reasons.
 - Other responsibilities are not assumed, please understand

Guarantee

This guarantee provides for free repair in accordance with the contents and items that have recorded. It is invalid if the necessary contents and items are out of this manual, so please read twice and keep a complete record in case of repairing.

- If the product works abnormally under the manual guide. You can apply for after service to the store you buy it.
- If the products are in the guarantee period, please contact the store or us for free repair.

We will charge for repair in the condition as follows, even in the warranty period.

- (1) The misuse and malfunction of the products and the damage caused by repair in private.
- (2) The malfunction caused by disaster like fire disasters, earthquake, thunder etc.
- (3) The malfunction and damage caused abnormally used. (Vocational use for a long time)
- (4) This guarantee hasn't recorded the date of purchase, customer name, sales name, or the guarantee contents are obliterated.

- *This guarantee will not be issued again, please keep it properly.
- *The product is not promised to keep data which stored in your devices if there is any damage occur.

We disclaim all responsibility for the loss or damage of the data in this situation.

Earnestly Promise

Your information in this guarantee will be only used for the repair. We will keep it confidential. We will not share to the third party without your agreement.



Lucky Sound Technology Co.,Ltd

Room 313, Building No.1, Yifang Industrial Park (138 Park), Hongye North No.1 Road Tangxia Town, Dongguan City, Guangdong Province, China
www.kong-x.com Email: info@kingkong88.com


Charge the Headphones

If the headphones battery power is running low, the product will play a confirmation tone through the headphones "Low Battery." for many times. Please place the headphones into the case.

Please use attached charging cable insert into the Micro USB jack to charge.

- Charge : Indicator lamps in red
- Charge Finish : Indicator lamps in blue.
- Charge Time : Approx. 2 Hours.

- ※ The headphones will power off after no pairing in a few mins.
- ※ Please release the charge cable after charge finish.
- ※ Battery power will lose if you long time no use.
- ※ Please recharge the product frequently.
- Battery included in the product can not change.



Abandon

The product contains battery. Please follow local environmental policy when you abandon the product.

Safety and Caution

To ensure safety, observe all warnings and cautions while using the product.

- | Caution | Caution | Warning |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| <p>Do not get wet
Avoid to electric leakage, crack, fire.</p> | <p>Do not allow product being exposed to the sunlight.
Avoid to battery fluid leakage, crack and fire, especially in low power.</p> | |
| <p>Do not touch fluid with bare hands
If fluid gets in your eyes, wash your eyes immediately. If your skin in contact with fluid, immediately wash the affected skin with water. If you experience eyes or skin irritation, consult doctor.</p> | | |
| | <p>Charge only with the included USB Cable .
When charging, make sure to use the included USB charging cable to avoid malfunction or fire.</p> | |
| | <p>Do not use the product if it is abnormal.
Do not use the product from a device if the product begins to malfunction, producing smoke, odor, heat, unwanted noise or showing other signs of damage.</p> | |
| <p>Do not disassemble, modify.
Do not disassemble, modify or attempt to repair the products to avoid electric shock, malfunction or fire.</p> | <p>Do not allow the product to get wet
Do not allow the product to get wet to avoid electric shock or malfunction</p> | |
| | <p>Do not use the product if you are cycling or driving.
Do not use the product to avoid the accidents when you are cycling or driving.</p> | |
| | <p>Do not use the products in loud volume in places where need to caution.
The product effectively shields external sound, so you may not hear ambient sound around you while hearing the product. Adjust the volume to a level where you can still hear background sound.</p> | |
| | <p>Discontinue use if skin irritation or feel sick.
If you begin to feel sick or skin irritation, please discontinue use immediately.</p> | |
| | <p>Do not use the product in place where has magnetic equipment.
Radio waves may affect cardiac pacemakers and medical electronic equipment.</p> | |

KX-200BT Guarantee

Warrant Period : 1 Year Since Purchase

Product Name		KX-200BT		
Purchase Date		Year	Month	Day
※	Name:			
	Address:			
	Phone Number:			
Store you purchase Product				
※ Name; Address; Contact Way:				