# HMC-K980TWS

User manual/ Guarantee

Sincerely thank you for choosing this product
in order to use it in right way
please read this user manual seriously
and keep it after reading.

Bluetooth®

Packaging contents·articles name· articles specification

This item includes below articles.
Please contact us if there is any missing or badness
when you first time use.

《Ear piece body / Detachable ear hook》

Detachable ear hook (right)

Detachable ear hook (Left)
Detachable ear hook (Right)

Earphone（L）
Earphone（R）

LED
Button
L（left） mark
R（right） mark
MIc

Charging terminal
L (left) mark
R (right) mark
Memory Foam eartip
(M size ear tips on earpieces)

《Silicone ear tips》

L×1set   M×1set   S×1set

《Charing/portable box》
Hook
LED
Charging terminal

《Charging cable   Length: about 25cm》

USB 2.0   microUSB

| Bluetooth Specification	
Communication mode : Bluetooth Ver. 5.0	
Output : Bluetooth class 2	
Max communication distance : 10M of visible range	
Frequency band : 2.4GHz	
Support profiles : A2DP, AVRCP, HFP, HSP	
Support decoder : SBC, AAC_LC	
Frequency : 20 - 20,200Hz	
Muilti pairing : 10 Devices (keep pairing set records)	
Multi point : Non - correspondence	
Max last play time : about 5 hours	
Max phone call time : about 5 hours	
Max standby time : about 200 hours	
Charging box battery : 700mAh Li - polymer	
Self charging time : about 2 hours	

Earphone Specification
Type : Hybrid
Driver : φ10mm Titanium film + Single balanced armature
Magnet : High magnet force
Play frequency : 20 - 40,000Hz
Impedance : 52Ω
Max Input power : 5mW
Sensitivete : 105dB/mW
Earphone battery : 60mAh coin battery
Self charging time : about 1 hours
Ear tips : Silicone eartips(L , M , S size ear tips) Memory foam eartip (M size ear tips with earpiece)

## Pairing and connect for earbuds and devices (the first time)

（ First time pairing ）

❶ Take out the earbuds from
the charging box, then press and
hold the left and right side ear buds
buttons at the same time untill
green light flash.
After that it's ready to pairing automatic.

※ Left side LED flashes fast while
right side LED flashes slowly (3s/time)
means complete pairing,
then proceed to next step.
※ Release the button while green light on .

Press simultaneously

Green LED light flashes
▼
Auto-pairing begin
▼
Left side LED flashes quickly
▼
Auto-pairing finished

❷ Turn on the bluetooth of your devices, search available devices,
then find out【HMC-K980】among the bluetooth devices, choose it.
If HMC-K980 shows connected,
it means successful connection.

Turn on the bluetooth
find out【HMC-K980】
among the bluetooth
devices, and choose it

Bluetooth
Bluetooth
Bluetooth device1
Bluetooth device2
Bluetooth device3
HMC-K980TWS

If HMC-K980 shows
"connection complete"
it means sucessful
connetion.

Bluetooth
Bluetooth
HMC-K980TWS   connect
Bluetooth device1
Bluetooth device2
Bluetooth device3

Pairing and connecting for ear buds and devices (from the secend time on)

（ From the secend time on ）

❶ Take out the ear buds from the charging box,
then press and hold both left and
right side ear buds buttons at the same time
until the green light flash .
After that, it's ready to pair automatic.
※ Left side LED flashes fast while right side
LED flash slowly (3s/time) means
complete pairing.
Then proceed to the next step
※ Release the button while green light on.

❷ Turn on the bluetooth of the connected
devices and search the available devices.
Then find out【HMC-K980】among
the bluetooth devices, choose it.
If it shows "connected",
it means successful connection.

Bluetooth
Bluetooth
HMC-980TWS
Bluetooth device1
Bluetooth device2
Bluetooth device3

Pair HMC-K980TWS in devices.
find out【HMC-K980】
among the bluetooth devices,
and choose it If HMC-K980TWS
shows "connection complete",
it means sucessful connection.

（ If connected failed ）

The situations of pairing failed "No【HMC-K980】 display in the bluetooth
devices list" or can't connect while choosing it,
Please put the ear buds back to the charging box, reconnect.
at once. When putting the earbuds into the box, the power will cut off.

Assembly method of the ear tips and ear hook

2 kinds of ear tips inclusive, Choose the fit size pair for replacement.
・ear tips : silicone eartips (L,M,S size each size one pair)
・Memory Foam eartip (M size ear tips with earpiece)

insert completely

inlay part

Confirm the direction
of the ear hook,
and then inset
the ear hook into
the ear pieces

The ear hook is flexible,
can change the shape freely,
adjust it till conplete fit your ear.

The changes of ear tips will caused different sound effects. In additon,
suitable size ear tips can decrease leaky.

Operation for music play

The function of the left and right buttons is the same, operating either one is feasible.

Open the music App in bluetooth devices first and play music in the device for the first time .

When music playing　single press ... pause

When music playing　double press ... next

When music playing　triple press ... replay last song

※ In the situation of replaying the last song,
Please press extra 3 times again
after pressing 3 time for replay current song.

When music pause　single press to continue

This product can't control volume on ear buds, please adjust the volume on devices when you need artist and music choose, control on devices please.
According to differences among different APPs,
it may replay current song when triple press the button
Because of differences among different APPs
control from the devices may invalid.
In this situation, all control in this product will not be available.

Operation for phone call

The function of the left and right buttons is the same, operating either one is the same.

※ According to differences among different call softwares, it maybe an issue that extenal contorl is invalid .

incoming call　single press ... answer the call

In-call　single press ... hang up

incoming call　press　for　3s ... rejection

※ This product can't control volume on ear buds, please adjust volume on devices when you need

Charging for earbuds and charging box

〔 Charging for earbuds 〕
→ Put the earbuds into the charging box to charge when they run out of battery.

operate on left　operate on right

LED light red while charging
→LED light off when charging complete

Close the cover

※Once put the earbuds into the box, power will cut off

〔 Charing for charging box 〕
Charging the charging box with a cable while the battey below 25% of full capacity.
・LED lights flash alternately while charging
・All 4 Led lights are on while charging complete

100%　75%　50%　25%
(green)　(green)　(green)　(red)

open the charging ermina cover and connect

Connect with USB cable after

Set up for pairing multi devices

〔 Set up for pairing multi device 〕 ～memorize history connected devices record function/ max 10 devices～

This item have pairing multi devices function (Record Max 10 bluetooth devices)
Obey the instruction of [pairing and connect for ear buds and devices (the first time)] when pairing the devices from the second one on.

※Pairing the devices from the second one on, relieve other connected bluetooth devices first
※Pairing the devices from the tenth one on, relieve before connected devices first.

Maximal remain 10 devices record

Abnormal situations of bluetooth connection (conditions and solutions)

〔 Disconnect / reasons and solutions for disconnect 〕

1. There is an obstacle between the device and the earphones (such as the device and the earphones are across the room). In different use situations, it may disconnect time to time.
2. May connect unstable while bluetooth devices connect WIFI simultaneously.
3. May connect unstable when other APPS open/stand by other bluetooth device
4. When earbuds in low battery
【Other solutions】
※ Besides the situations above, Please try these solutions when connect off-state.
→ Turn off the connection of the earbuds and the device, then reconnect them.
→ Relieve the the connection between the earbuds and the device, then reconnect. （same to first connect）
→ Restart conncted device(smart phone, etc)

--- Warning ---
1. This product use a 2.4GHz band of radio waves used in electronics, chemistry, medical equipment, radio waves may disturbed or deviant when the same band equipment close to.
2. Keep 3m distance at least to other electric devices. there are also cases of radio waves blocking by electronic products.
3. Please keep away from radio to avoid noise disturbances.
4. Keep the distances between this product and device in the range of 10m. There are also cases of communication distance shortening due to different space structures or obstacles.
5. If the wireless equipment is unable to communicate due to its proximity to the radio station, please change the place of communication.
6. If the product and the connecting device put into the handbag or pocket while working, because of the bluetooth transceiver signal limited transmited, the sound will be disconnected or have noises.
7. This product conforms to the technical standard of radio wave method, and does not need the license of radio station for each use.
※ Damage caused by the use of this product, our company shall not bear any liability except for legally recognized liability for compensation.
※ We can not assure the product connect all bluetooth devices will successful, our company shal not be liable for any communication error or abnormality of the customer's connection equipment.
・In order to improve the product, the specifications and appearance will also be changed without notice, please understand
・We will replace the defective products with new ones for manufacturing reasons. Other responsibilities are not assumed, please understand.

Assurance provisions and guarantee

This guarantee provides for free repair in accordance with the contents recorded, this guarantee shall be involid in the event that necessary matters are not recorded, so please be sure to keep a complete record.
1. In case of failure under normal conditions according to the operating instructions, please submit the application to our company or the purchased sales store.
2. Free repair within the guarantee period, please submit this product and this guarantee to our company or the sales store you purchased.
3. Repair costs for the following situations during the warranty period.
① malfunction and damage caused by repair or modification and misuse.
② malfunction and damage caused by fire, earthquake, flood, lightning and other natural disasters, public hazards or abnormal voltage
③ malfunction and damage caused by situations that are not normally used(such as long time using)
④ This guarantee does not record the date of purchase, customer name , sales name, or the guarantee be changed.
＊This guarantee will not be issued again, please keep it properly.
＊The product won't be guaranteed to keep the data which storded in the customer's equipment if the malfunction and damage occured. we shall not be liable for any direct or indirect damage.

HMC-K980TWS			
Guarantee period	One year form Purchase date　M　　D　　Y		
Customer	Name		
	ADDRESS		
	PHONE NUMBER		
Sales store			